

## **AC SMARTSEAL INSTRUCTIONS**

**Dose: Approximately 2 oz (60 ml) on systems up to 10 tons. 4 oz (120 ml) up to 20 tons.**

- 1. Use under 40 psi. If needed, perform a pump down by closing high side valve to reduce low side pressure.**
- 2. Connect male adapter to end of syringe, and purge air out of hose by pushing sealant through clear hose.**
- 3. Connect female adapter to low-pressure port side and push in with the syringe plunger.**
- 4. Allow 30 minutes for the seal to take place with system running.**

**\*Cannot be used on high (liquid) side, only low side.**